

## Service precautions

Vehicle maintenance is an important yet frequently neglected item. Proper maintenance will aid in retaining the level of performance that has been engineered into your Mitsubishi vehicle and it will guard against major repair expenses resulting from neglect. Good maintenance is necessary to protect your investment and ensure proper performance.

Your Mitsubishi Motors Dealership is in the best position to provide proper maintenance service through Mitsubishi's exclusive "Diamond Care Service".

- Factory Trained Technicians
- Advanced Diagnostic Equipment
- Quality Workmanship
- Genuine Mitsubishi Parts
- Genuine Mitsubishi Accessories
- Competitive Prices
- Fast Service
- Commitment to Customer Satisfaction

## Selecting the proper maintenance schedule

There are two maintenance schedules that show proper service for your vehicle.

### Schedule 1

Use Schedule 1 if you primarily operate your vehicle under any of these conditions;

- Driving on dusty, rough, muddy or salt-spread roads
- Police, taxi or commercial operation
- Extended use of brakes while driving
- Driving in sandy areas
- More than 50 % operation in heavy city traffic during hot weather above 90 °F (32 °C)

### Schedule 2

Use Schedule 2 only if you primarily operate your vehicle under conditions other than those listed in Schedule 1.

# Schedule 1

## Schedule 1

MAINTENANCE ITEM	MAINTENANCE INTERVAL (Mileage or Time- whichever occurs first)																					
	miles x 1,000	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	127.5	135	142.5	150	
	km x 1,000	12	24	36	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	228	240	
	months	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120	
Check transmission oil level and condition		X					X			X					X					X		
Change transmission oil					X				X				X				X					X
Inspect coolant hoses condition (radiator hose, heater hose)					X				X				X				X					X
Inspect high voltage wire for looseness and damage					X				X				X				X					X
Change motor coolant	Every 240 months																					
Change heater fluid	Every 240 months																					
Inspect disc brake pads and rotors for wear	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Inspect rear drum brake linings and rear wheel cylinders for wear and leaks		X		X		X		X		X		X		X		X		X		X		X
Check brake hoses for deterioration or leaks		X		X		X		X		X		X		X		X		X		X		X
Change brake fluid						X							X							X		
Inspect ball joint and steering linkage seals for grease leaks and damage					X				X				X				X					X
Inspect driveshaft boots for grease leaks and damage		X		X		X		X		X		X		X		X		X		X		X
Inspect suspension system for looseness and damage	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Inspect air purifier filter for clogging	Every 3,750 miles (6,000 km) or every 3 months																					
Replace air purifier filter	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Check tire repair sealant expiration date	Every 12 months																					

# Schedule 2

MAINTENANCE ITEM	MAINTENANCE INTERVAL (Mileage or Time- whichever occurs first)																				
	miles x 1,000	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	127.5	135	142.5	150
	km x 1,000	12	24	36	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	228	240
	months	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
Check transmission oil level and condition			X		X		X		X		X		X		X		X		X		X
Inspect coolant hoses condition (radiator hose, heater hose)					X				X				X				X				X
Inspect high voltage wire for looseness and damage					X				X				X				X				X
Change motor coolant	Every 240 months																				
Change heater fluid	Every 240 months																				
Inspect disc brake pads and rotors for wear		X			X		X		X		X		X		X		X		X		X
Inspect rear drum brake linings and rear wheel cylinders for wear and leaks					X				X				X				X				X
Check brake hoses for deterioration or leaks		X			X		X		X		X		X		X		X		X		X
Change brake fluid							X						X							X	
Inspect ball joint and steering linkage seals for grease leaks and damage					X				X				X				X				X
Inspect driveshaft boots for grease leaks and damage		X			X		X		X		X		X		X		X		X		X
Inspect suspension system for looseness and damage					X				X				X				X				X
Replace air purifier filter		X			X		X		X		X		X		X		X		X		X
Check tire repair sealant expiration date	Every 12 months																				

# Maintenance Record

## Maintenance Record

<b>3,750 Miles (6,000 km) or 3 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____	<b>7,500 Miles (12,000 km) or 6 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____	<b>11,250 Miles (18,000 km) or 9 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____
<b>15,000 Miles (24,000 km) or 12 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____	<b>18,750 Miles (30,000 km) or 15 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____	<b>22,500 Miles (36,000 km) or 18 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____
<b>26,250 Miles (42,000 km) or 21 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____	<b>30,000 Miles (48,000 km) or 24 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____	<b>33,750 Miles (54,000 km) or 27 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____  DATE: _____ REPAIR ORDER #: _____

## Maintenance Record

<p><b>37,500 Miles (60,000 km) or 30 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>41,250 Miles (66,000 km) or 33 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>45,000 Miles (72,000 km) or 36 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>
<p><b>48,750 Miles (78,000 km) or 39 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>52,500 Miles (84,000 km) or 42 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>56,250 Miles (90,000 km) or 45 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>
<p><b>60,000 Miles (96,000 km) or 48 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>63,750 Miles (102,000 km) or 51 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>67,500 Miles (108,000 km) or 54 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>

## Maintenance Record


<p><b>71,250 Miles (114,000 km) or 57 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>75,000 Miles (120,000 km) or 60 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>78,750 Miles (126,000 km) or 63 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>
<p><b>82,500 Miles (132,000 km) or 66 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>86,250 Miles (138,000 km) or 69 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>90,000 Miles (144,000 km) or 72 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>
<p><b>93,750 Miles (150,000 km) or 75 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>97,500 Miles (156,000 km) or 78 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>101,250 Miles (162,000 km) or 81 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>

<p><b>105,000 Miles (168,000 km) or 84 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>108,750 Miles (174,000 km) or 87 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>112,500 Miles (180,000 km) or 90 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>
<p><b>116,250 Miles (186,000 km) or 93 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>120,000 Miles (192,000 km) or 96 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>123,750 Miles (198,000 km) or 99 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>
<p><b>127,500 Miles (204,000 km) or 102 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>131,250 Miles (210,000 km) or 105 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>	<p><b>135,000 Miles (216,000 km) or 108 months</b></p> <p>MILEAGE/ MONTHS: _____</p> <p>DEALERSHIP NAME/CODE: _____</p> <p>DATE: _____</p> <p>REPAIR ORDER #: _____</p>

## Maintenance Record

<b>138,750 Miles (222,000 km) or 111 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____ DATE: _____ REPAIR ORDER #: _____	<b>142,500 Miles (228,000 km) or 114 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____ DATE: _____ REPAIR ORDER #: _____	<b>146,250 Miles (234,000 km) or 117 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____ DATE: _____ REPAIR ORDER #: _____
<b>150,000 Miles (240,000 km) or 120 months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____ DATE: _____ REPAIR ORDER #: _____		<b>240 Months</b> MILEAGE/ MONTHS: _____ DEALERSHIP NAME/CODE: _____ DATE: _____ REPAIR ORDER #: _____






**MITSUBISHI  
MOTORS**

---

**DIAMOND CARE  
PROTECTION PLAN**

Have you purchased the Mitsubishi Diamond Care Protection Plan?  
The Plan supplements your new vehicle warranties. See your  
authorized Mitsubishi dealer for details.



## OWNER INFORMATION

OWNER'S NAME		
ADDRESS		
CITY	STATE	ZIP

## VEHICLE / DEALER INFORMATION

VEHICLE IDENTIFICATION NUMBER																
WARRANTY START (IN-SERVICE) DATE								MILEAGE AT START OF WARRANTY								
SELLING DEALER NAME												DEALER CODE				
ADDRESS																
CITY	STATE								ZIP							

## DIAMOND CARE PROTECTION PLAN INFORMATION (IF APPLICABLE)

POLICY NUMBER										EXPIRATION DATE					
MONTHS OF COVERAGE								EXPIRATION MILEAGE							

### IMPORTANT NOTICE TO OWNER

PLEASE PRESENT THIS BOOKLET TO ANY AUTHORIZED MITSUBISHI MOTORS DEALER OR AUTHORIZED SERVICE CENTER FOR WARRANTY SERVICE ON THE ABOVE LISTED VEHICLE.

